



Mounting Instructions

For the mounting of the bumper the mounting plate has to be fastened with M6 screws. The distance between **A** and **B** has to be in between **20** and **40** mm.

Drill a cable entry ($\varnothing 18$ mm) for the connection cable into an appropriate place on the mounting plate. If the bumper is supposed to be connected to another bumper, a further cable entry has to be drilled. In order to prevent damage of the connection cable, each cable entry has to be deburred **carefully** and provided with a protection sleeve!

Lead the connection cable(s) through the protection sleeve(s) and slide the bumper onto the mounting plate up to the stop. When the bumper is adjusted correctly, drill **D** $\varnothing 5,2$ mm holes in even distance **C** (**not more than 200** mm) through the mounting plate. Then insert provided expanding rivets. Check, if all installation components are firmly joined.